Instruction Manual I Bedienungsanleitung I Manuel d'utilisation I Manuale di Istruzioni

Il instructions, warranties and other collateral documents are subject to change at the sole discretion of Horizon Hobby, Inc. For up-to-date product literature, visit horizonhobby.com and click on the support tab for this product.

Meaning of Special Language

The following terms are used throughout the product literature to indicate various levels of potential harm when operating this product:

NOTICE: Procedures, which if not properly followed, create a possibility of physical property damage AND a little or no possibility of injury. CAUTION: Procedures, which if not properly followed, create the probability of physical property damage AND a possibility of serious injury. WARNING: Procedures, which if not properly followed, create the probability of property damage, collateral damage, and serious injury OR create a high probability of superficial injury.

WARNING: Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause serious injury.

This is a sophisticated hobby product. It must be operated with caution and common sense and requires some basic mechanical ability. Failure to operate this Product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not intended for use by children without direct adult supervision. Do not attempt disassembly, use with incompatible components or augment product in any way without the approval of Horizon Hobby, Inc. This manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup or use, in order to operate correctly and avoid damage or serious injury.

Age Recommendation: Not for children under 14 years. This is not a toy.

Please visit www.horizonhobby.com for the most up-to-date technical manual for translations and changes.

Thank you for purchasing the E-flite® 30-Amp Pro Switch-mode BEC Brushless ESC (V2). This is a high-quality sensorless brushless electronic speed control with an integrated switch-mode BEC that is very lightweight and efficient. It can operate without the need for a separate receiver battery to power your servos and receivers, saving you weight and complication.

SPECIFICATIONS

Continuous Current 30A*

Max Burst Current 35A (15 sec)*

* Proper cooling and airflow required

Length 51.0mm (2.00 in)

Width 28.0mm (1.10 in)

Height 8.70mm (0.35 in)

Weight 31.0 g (1.10 oz)

Battery Input Leads 16 AWG with E-flite EC3 Connector

Cells 3-4S Li-Po or 9-12 Ni-MH/Ni-Cd

Motor Output Leads 16 AWG with 3.5mm Gold Bullet Connectors

FEATURES

- Up to 30 amps continuous current with proper air flow and 35 amps burst current (15 seconds)
- 3.5A* continuous current, 5V Switch-Mode BEC Circuit
- Stronger BEC for support of most 3-axis stabilization systems
- Drive up to 7 analog or 6 digital standard-size servos with the BEC on any recommended input voltage
- 3- to 4-cell Li-Po, 9- to 12-cell Ni-MH/Ni-Cd input voltage
- Programmable motor braking
- Safe power-arm mode prevents accidental starts • Programmable low voltage cutoff with settings for 3-cell Li-Po (9.2V),
- 4-cell Li-Po (12V) or 74% of battery starting voltage
- Programmable throttle input range (1.1ms–1.9ms or 1.2ms–1.8ms)
- Programmable soft start for helis and airplanes
- Auto motor shut down if signal is lost or there is interference
- Programmable timing—5 user-selectable ranges for use with a large
- variety of brushless motors Pre-wired connectors—E-flite EC3[™] connector on battery input and
- 3.5mm gold bullet connectors on motor output leads
- * Proper cooling and airflow required

SERVO RATINGS WITH BEC ENABLED

Drives up to 7 analog or 6 digital standard-size servos with the BEC on any recommended input voltage. Some servo combinations that have been tested in various models include

- 1 analog standard servo, 1 digital sub-micro servo, 2 analog sub-micro servos—E-flite Apprentice® 15e RTF
- 2 ParkZone® (PKZ1081) analog sub-micro servos and 2 ParkZone (PKZ1090) digital metal gear sub-micro servos—ParkZone T-28 Trojan RTF

Digital servos and binding servos of any kind typically have higher current draw. As a general rule, micro and sub-micro servos draw less current, which may affect your servo usage as shown in the examples above. We recommend installing a Hangar 9® Servo and Receiver Current Meter (HAN172), between the throttle lead of the ESC and receiver to confirm current draw of the actual servos used. Always position the ESC for maximum airflow; cooling can significantly aid in the performance of the BEC.

BEFORE FIRST USE

Please refer to "Servo Ratings with BEC Enabled" notes for BEC usage guidelines. You must follow these guidelines for safe operation. If you are using more than 7 analog standard servos, more than 6 digital standard servos or servos with higher current draw than the BEC can deliver, you will need to disable the BEC. If you wish to disable the BEC, you must remove the red receiver wire lead and connector from the receiver lead housing and then insulate it properly to prevent shorting. When operating with the BEC disabled, it is recommended to use a separate, high-power, external BEC, or receiver pack and switch.

The ESC comes prewired with an EC3 connector and is compatible with most batteries. Only use 3-4S Li-Po or 9-12 Ni-MH/Ni-Cd batteries Connect a fully charged battery to the ESC battery connector.

WARNING: Always remove the propeller before checking the startup function of the ESC or making programming changes. Keep all body parts, hair and loose clothing away from a moving propeller, as these items could become entangled.

WARNING: Always disconnect the battery when not flying to avoid over-discharging the battery. Batteries discharged to a voltage lower than the lowest approved voltage may become damaged, resulting in loss of performance and potential fire when batteries are charged.

When flying in hot weather, check on the condition of the ESC, battery and motor after each flight. Always let the electronic components cool to near ambient temperature between flights. During extreme conditions, throttle management is necessary when running near maximum levels of current draw. It is possible to cause permanent damage to the motor, battery and ESC if in full throttle the entire flight.

USING THE 30-AMP PRO SWITCH-MODE BEC BRUSHLESS ESC

This ESC is simple to use and, for safety, will not arm the motor until the throttle stick has been held in the Idle (low) position for more than 1 second. The ESC will indicate the soft cutoff voltage setting every time the battery is connected by first emitting a low, long tone to indicate startup. Depending on the selected cutoff voltage (default is 74%), you will then hear the respective number of medium-length mid-tones to indicate the cell count or a musical tone for the 74% cutoff, helping you to confirm the setting before every flight.

Proper air cooling is required during flights. The ESC should be placed in an area where air flows over the ESC.

CONNECTING THE ESC TO THE MOTOR

The three wires from the motor connect to the three gold bullet connectors on the ESC. The order of connection to the motor is not important; any motor wire can be connected to any connector. If the motor runs backwards, you can simply disconnect and switch any two of the motor wire plugs connected to the ESC.

MOUNTING THE ESC

1. Choose a location that has good airflow and offers good protection.

DO NOT cover the side with the flat heat shield with hook and loop tape, or any other material, as this will greatly reduce its effectiveness. 2. Mount the ESC with a combination of hook and loop tape, 2-sided foam tape and/or tie wraps.

STARTING YOUR POWER SYSTEM

- 1. Power ON your transmitter and ensure the position of the throttle is in the Idle (low) position.
- 2. Connect the battery to the ESC. You will hear 1 low, long tone to indicate startup, then the respective number of medium-length mid-tones to indicate the cell count or a musical tone for the 74% cutoff, followed by 3 rising tones to indicate the ESC is armed
- . When you move the throttle stick upward, the motor will run. Continue to move the throttle stick upward to full throttle (high position), and the motor will run faster. When the throttle stick goes below the start-up position, the motor will stop running.
- 4. Check the servo motion as part of your preflight check. It is very important to make sure linkages are free-moving with no binding. Remember, when in the programming mode:
- Idle = Stick Down Full Throttle = Stick Up
- The default settings for the ESC are as follows:
- Voltage cutoff set at 74% Timing set at 15 degrees
- Brake set to Off • Throttle Input Range set at 1.2ms to 1.8ms

PWM Frequency set at 8KHz

- Start-up Rate (Acceleration Delay) set at 0.25 seconds Operating Mode set to normal (airplane)

ENTERING THE PROGRAMMING MODE

- 1. With the battery disconnected from the ESC and the transmitter powered ON, move the throttle stick to full throttle. Hold full throttle, then connect the battery to the ESC.
- 2. Wait 5 seconds and the ESC will give two sets of fast ringing tones to indicate you have entered Programming Mode.
- 3. Once you hear these tones, move the stick to center for 5 seconds. The ESC will beep 1 time, indicating you are now in Menu 1.
- 4. The ESC will now wait 5 seconds for you to make your selection; your programming options are either full throttle or idle.
- 5. When you have made a valid selection, the ESC will beep once with a lower tone. Move the stick back to center for the next menu item (2 beeps, 3 beeps and so on), If you do not make a selection within 5 seconds, the ESC will move to the next menu item.
- 6. If you want to make changes in the programming menus (see specific instructions below), move the throttle stick to full throttle. You will have 5 seconds to make your selection.
- 7. If you want to advance to the next menu, allow the programming to skip to the next menu after the 5 seconds have expired.

PROGRAMMING MENU 1 – VOLTAGE CUTOFF

The default setting is 74% cutoff*

Use this option to set the voltage at which the ESC will shut down the motor to prevent damage to the battery when it reaches the cutoff voltage. You will know the battery has reached auto cutoff when you hear the motor "pulse" repeatedly

- 1. Move the throttle stick to full throttle to make changes to the voltage cutoff programming.
- a. To select 3-cell low voltage cutoff—You will hear 3 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection
- b. To select 4-cell low voltage cutoff—You will hear 4 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you
- have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection c. To select 74% cutoff—You will hear 7 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the

program selection. Leave in full throttle for 5 seconds to advance to the first selection again. *IMPORTANT NOTE ABOUT 74% CUTOFF: This option will activate the soft cutoff at 74% of the startup voltage or 9.2V, whichever is higher.

For example, if the battery measures 16.8 volts at startup, then the soft cutoff will occur at 12.4 volts. The 74% cutoff option will check the startup voltage every time you connect the battery to the ESC. Avoid using partially charged batteries, as the system cannot protect the Li-Po batteries if you are using the 74% cutoff and connect a partially charged batter

You will know the battery has reached soft auto cutoff when you hear the motor "pulse" repeatedly. Land your model as soon as you hear the motor pulse (indicating the battery voltage has dropped to the cutoff voltage level) to prevent over-discharge of the Li-Po battery and to prevent

PROGRAMMING MENU 2 – BRAKE TYPE

The default setting is Brake Off.

This option gives you the choice to have the ESC stop the propeller during flight (Brake On) or allow it to windmill (Brake Off). Use the Brake On options for folding propellers

- 1. Move the stick to center for 5 seconds and the ESC will beep 2 times, indicating you are now in Menu 2.
- 2. Move the throttle stick to full throttle to make changes to the Brake Type programming.

LOW TIMING ADVANCE

- a. To select No Brake/Brake Off—You will hear 1 short beep. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection
- b. To select Soft Brake—You will hear 2 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the
- program selection. Leave in full throttle for 5 seconds to advance to the next selection.
- c. To select Medium Brake—You will hear 3 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection.
- d. To select Hard Brake—You will hear 4 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the first selection again.

PROGRAMMING MENU 3 – TIMING

The default setting is 15 degrees.

As a general rule, lower pole count motors use lower timing and higher pole count motors use higher timing. Please refer to your motor instructions and specifications for an indication of the number of poles.

5 & 10 Timing Degrees Motor Poles 2 to 4 **Expected Performance** Good balance of power and efficiency Motor Poles Best efficiency and run time (lowest power) Expected Performance STANDARD TIMING ADVANCE Motor Poles 6 to 12 Good balance of power and efficiency Expected Performance Motor Poles 14 or more Best efficiency and run time (lowest power) Expected Performance HIGH TIMING ADVANCE Timing Degrees 25 Motor Pole Expected Performance Highest power, less efficiency

- Expected Performance Good balance of power and efficiency 1. Move the stick to center for 5 seconds and the ESC will beep 3 times, indicating you are now in Menu 3.
- 2. Move the throttle stick to full throttle position to make changes to the Timing programming.

Motor Poles

a. To select 5 Degrees—You will hear 1 short beep. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection.

14 or more

- b. To select 10 Degrees—You will hear 2 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection. c. To select 15 Degrees—You will hear 3 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the
- program selection. Leave in full throttle for 5 seconds to advance to the next selection. d. To select 20 Degrees—You will hear 4 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the
- program selection. Leave in full throttle for 5 seconds to advance to the next selection. e. To select 25 Degrees—You will hear 5 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the first selection again.

PROGRAMMING MENU 4 - THROTTLE INPUT RANGE (PWM)

The default setting is 1.2ms to 1.8ms (works with most radio systems).

This option allows for proper throttle input with many different radio systems. However, some radios have a wider output range, and may give a more linear response with the 1.1ms to 1.9ms range. If you feel there is too much "dead" area in the stick movement near full throttle, try adjusting the end points in your radio, or change to the wider input range. Be aware that if these settings are not correct, it may be impossible to arm the ESC.

- 1. Move the stick to center for 5 seconds and the ESC will beep 4 times, indicating you are now in Menu 4.
- 2. Move the throttle stick to full throttle to make changes to the Throttle Input Range programming.
- a. To select 1.2ms to 1.8ms—You will hear 1 short beep. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection.
- b. To select 1.1ms to 1.9ms—You will hear 2 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the first selection again.

PROGRAMMING MENU 5 - START-UP RATE

The default setting is 0.25 second

The start-up rate is the time it takes to reach maximum motor speed. Changing the setting to 1 second can be useful with power-fragile gear

1. Move the stick to center for 5 seconds and the ESC will beep 5 times, indicating you are now in Menu 3.

program selection. Leave in full throttle for 5 seconds to advance to the next selection.

- 2. Move the throttle stick to full throttle position to make changes to the Start-up Rate programming. a. To select .25 second—You will hear 1 short beep. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the
- b. To select 1 second—You will hear 2 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the first selection again.

PROGRAMMING MENU 6 - PWM SWITCHING FREQUENCY

The default setting is 8KHz (acceptable for most motors).

If you have a low or very low inductance motor and know you need to use a higher PWM Frequency (refer to the manual included with the motor), then you can change the setting. Otherwise, we recommend leaving the default setting.

- 1. Move the stick to center for 5 seconds and the ESC will beep 6 times, indicating you are now in Menu 6.
- 2. Move the throttle stick to full throttle to make changes to the PWM Switching Frequency programming a. To select 8KHz PWM Frequency—You will hear 1 short beep. Move the throttle stick to center. The ESC will beep 2 times, indicating you
- have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection
- b. To select 16KHz PWM Frequency—You will hear 2 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection.
- c. To select 32KHz PWM Frequency—You will hear 3 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the first selection again

PROGRAMMING MENU 7 – OPERATING MODE

The default setting is set to Normal (airplane) Mode (which is limited to a start-up rate of 0.25 or 1 second).

Alternatively, the Heli Mode can be selected which, reduces the start-up rate to 5 seconds for the first start-up and any start-up after the motor/ ESC has been stopped for more than 5 seconds. This helps to prevent damaging the motor, gears or any other components from an abrupt start-up when none of the parts are moving. Any time the motor/ESC has been stopped for less than 5 seconds in Heli Mode, the start-up will be immediate. This allows power to be applied immediately, such as when aborting an auto-rotation attempt or to help prevent a crash. Remember, you must wait more than 5 seconds after stopping the motor/ESC in order for the 5-second start-up to occur again.

- 1. Move the stick to center for 5 seconds and the ESC will beep 7 times, indicating you are now in Menu 7.
- 2. Move the throttle stick to full throttle to make changes to the Operating Mode programming.
- a. To select Normal Mode—You will hear 1 short beep. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the program selection. Leave in full throttle for 5 seconds to advance to the next selection. b. To select Heli Mode—You will hear 2 short beeps. Move the throttle stick to center. The ESC will beep 2 times, indicating you have set the
- program selection. Leave in full throttle for 5 seconds to advance to the first selection again.

The ESC will beep more quietly than normal if the input voltage is below the cutoff voltage when the battery is connected. Check the voltage of the battery to see if it is correct (charged), or the programmed cutoff setting of the input voltage is set incorrectly for the voltage of the pack being

If you have trouble arming the ESC (and the throttle trim has been set to minimum), enter the programming mode and try changing the setting to 1.1ms-1.9ms in Programming Menu 4 to see if it helps correct the problem. If it is a computer radio, you may alternatively increase high and low

throttle ATV (endpoint) percentages

Increasing the high ATV will not have a consequence on arming issues, only low ATV. Some transmitters, including all Futaba transmitters, will require the throttle channel to be "reversed" for proper operation.

1 YEAR LIMITED WARRANTY

What this Warranty Covers - Horizon Hobby, Inc., (Horizon) warrants Product, purchaser is advised to return the Product immediately in new to the original purchaser that the product purchased (the "Product") will and unused condition to the place of purchase. be free from defects in materials and workmanship for a period of 1 Law - These terms are governed by Illinois law (without regard to conflict of law principals). This warranty gives you specific legal rights, and you years from the date of purchase.

What is Not Covered - This warranty is not transferable and does may also have other rights which vary from state to state. Horizon reserves not cover (i) cosmetic damage, (ii) damage due to acts of God, ac- the right to change or modify this warranty at any time without notice. cident, misuse, abuse, negligence, commercial use, or due to WARRANTY SERVICES NO OTHER WARRANTY OR REPRESENTATION, AND HEREBY DIS- website at www.ho OUT LIMITATION, THE IMPLIED WARRANTIES OF NON-INFRINGE- sentative.

RANTY IS THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY is asserted. As Horizon has no control over use, setup, final assembly, are clearly written on the outside of the shipping carton the user accepts all resulting liability. If you as the purchaser or user zon Product Support office.

are not prepared to accept the liability associated with the use of the

improper use, installation, operation or maintenance, (iii) modifi- Questions, Assistance, and Services - Your local hobby store and/ cation of or to any part of the Product, (iv) attempted service by or place of purchase cannot provide warranty support or service. Once

anyone other than a Horizon Hobby authorized service center, assembly, setup or use of the Product has been started, you must con-(v) Product not purchased from an authorized Horizon dealer, or tact your local distributor or Horizon directly. This will enable Horizon (vi) Product not compliant with applicable technical regulations, to better answer your questions and service you in the event that you OTHER THAN THE EXPRESS WARRANTY ABOVE, HORIZON MAKES may need any assistance. For questions or assistance, please visit our CLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITH- or call 877.504.0233 toll free to speak to a Product Support repre-MENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR Inspection or Services - If this Product needs to be inspected or PURPOSE. THE PURCHASER ACKNOWLEDGES THAT THEY ALONE serviced and is compliant in the country you live and use the Product

HAVE DETERMINED THAT THE PRODUCT WILL SUITABLY MEET in, please use the Horizon Online Service Request submission process THE REQUIREMENTS OF THE PURCHASER'S INTENDED USE, found on our website or call Horizon to obtain a Return Merchandise Purchaser's Remedy - Horizon's sole obligation and purchaser's sole Authorization (RMA) number. Pack the Product securely using a shipand exclusive remedy shall be that Horizon will, at its option, either (i) ping carton. Please note that original boxes may be included, but are service, or (ii) replace, any Product determined by Horizon to be defec- not designed to withstand the rigors of shipping without additional tive. Horizon reserves the right to inspect any and all Product(s) involved protection. Ship via a carrier that provides tracking and insurance for in a warranty claim. Service or replacement decisions are at the sole lost or damaged parcels, as Horizon is not responsible for merchandise discretion of Horizon. Proof of purchase is required for all warranty until it arrives and is accepted at our facility. An Online Service Request claims. SERVICE OR REPLACEMENT AS PROVIDED UNDER THIS WAR- is available at http://www.horizonhobby.com/content/_service-center_render-service-center. If you do not have internet access, please Limitation of Liability - HORIZON SHALL NOT BE LIABLE FOR SPE- contact Horizon Product Support to obtain a RMA number along with CIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSS instructions for submitting your product for service. When calling Hori-OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY, zon, you will be asked to provide your complete name, street address, REGARDLESS OF WHETHER SUCH CLAIM IS BASED IN CONTRACT, email address and phone number where you can be reached during WARRANTY, TORT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER business hours. When sending product into Horizon, please include THEORY OF LIABILITY, EVEN IF HORIZON HAS BEEN ADVISED OF THE your RMA number, a list of the included items, and a brief summary of POSSIBILITY OF SUCH DAMAGES. Further, in no event shall the liability the problem. A copy of your original sales receipt must be included for of Horizon exceed the individual price of the Product on which liability warranty consideration. Be sure your name, address, and RMA number

modification or misuse, no liability shall be assumed nor accepted for NOTICE: Do not ship LiPo batteries to Horizon. If you have any any resulting damage or injury. By the act of use, setup or assembly, issue with a LiPo battery, please contact the appropriate Hori-

Warranty Requirements - For Warranty consideration, you must include your original sales receipt verifying the proofof-purchase date. Provided warranty conditions have been met, your Product will be serviced or replaced free of charge. Service or replacement decisions are at the sole discretion of Horizon.

Non-Warranty Service - Should your service not be covered by warranty, service will be completed and payment will be required without notification or estimate of the expense unless the expense exceeds 50% of the retail purchase cost. By submitting the item for service, it will be returned unserviced at without notification. Service estimates are available upon request. You the sole expense of the purchaser must include this request with your item submitted for service. Non-

warranty service estimates will be billed a minimum of ½ hour of labor. In addition you will be billed for return freight. Horizon accepts money orders and cashier's checks, as well as Visa, MasterCard, American Express, and Discover cards. By submitting any item to Horizon for service, you are agreeing to Horizon's Terms and Conditions found on our website http://www.horizonhobby.com/content/_service-center_render-service-center.

NOTICE: Horizon service is limited to Product compliant in the country of use and ownership. If non-compliant product is re-

WARRANTY AND SERVICE CONTACT INFORMATION

Country of Purchase	Horizon Hobby	Address	Phone Number/Email Address
United States of America	Horizon Service Center (Electronics and engines)	4105 Fieldstone Rd Champaign, Illinois, 61822 USA	877-504-0233 Online Repair Request: visit www.horizonhobby.com/service
	Horizon Product Support (All other products)		877-504-0233 productsupport@horizonhobby.com
United Kingdom	Horizon Hobby Limited	Units 1-4 , Ployters Rd, Staple Tye, Harlow, Essex, CM18 7NS, United Kingdom	+44 (0) 1279 641 097 sales@horizonhobby.co.uk
Germany	Horizon Technischer Service	Christian-Junge-Straße 1 25337 Elmshorn, Germany	+49 (0) 4121 2655 100 service@horizonhobby.de
France	Horizon Hobby SAS	11 Rue Georges Charpak 77127 Lieusaint, France	+33 (0) 1 60 18 34 90 infofrance@horizonhobby.com
China	Horizon Hobby – China	Room 506, No. 97 Changshou Rd. Shanghai, China 200060	+86 (021) 5180 9868 info@horizonhobby.com.cn

PARTS CONTACT INFORMATION

Country of Purchase	Horizon Hobby	Address	Phone Number/Email Address	
United States of America	Sales	4105 Fieldstone Rd Champaign, Illinois, 61822 USA	800-338-4639 sales@horizonhobby.com	
United Kingdom	Horizon Hobby Limited	Units 1-4, Ployters Rd, Staple Tye Harlow, Essex, CM18 7NS, United Kingdom	+44 (0) 1279 641 097 sales@horizonhobby.co.uk	
Germany	Horizon Hobby GmbH	Christian-Junge-Straße 1 25337 Elmshorn, Germany	+49 (0) 4121 2655 100 service@horizonhobby.de	
France	Horizon Hobby SAS	11 Rue Georges Charpak 77127 Lieusaint, France	+33 (0) 1 60 18 34 90 infofrance@horizonhobby.com	
China	Horizon Hobby – China	Room 506, No. 97 Changshou Rd. Shanghai, China 200060	+86 (021) 5180 9868 info@horizonhobby.com.cn	

COMPLIANCE INFORMATION FOR THE EUROPEAN UNION

Declaration of Conformity (in accordance with ISO/IEC 17050-1)

No. HH2012111902

EFL 30A ESC Product(s): Item Number(s):

The object of declaration described above is in conformity with the requirements of the specifications listed below, following the provisions of

the EMC Directive 2004/108/EC: EN55022:2010 + AC:2011

Champaign, IL USA

November 19, 2012

EN55024:2010

Signed for and on behalf of:

DE a Hall Horizon Hobby, Inc.

Steven A. Hall Executive Vice President and Chief Operating Officer International Operations and Risk Management

Horizon Hobby, Inc.

Instructions for disposal of WEEE by users in the European Union

This product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collections point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or where you purchased the product.

E-flite, EC3, Apprentice, ParkZone and Hangar 9 are trademarks or registered trademarks of Horizon Hobby, Inc. The Spektrum trademark is used with permission of Bachmann Industries, Inc. Futaba is a registered trademark of Futaba Denshi Kogyo Kabushiki Kaisha Corporation of Japan.